

PARTS LIST FOR ACCESSORY

NO.	PART NAME	PART NO.	SPECIFICATION	REMARK
1	CONTROL BOX COVER	P02039		
2	SCREW	T14006	M4X 6	
3	CONTROL BOX HOUSING	P02040		
4	SOLENOID VALVE SET	PDC6		
5	SOLENOID VALVE	PDC3-1		
6	CIRCUIT CONNECTOR	E60004		
7	WIRE	E11102	18AWG	
8	RAPIR JOINT	A20001	SPL-4-01	
9	RAPIR JOINT	A20002	SPL-06-01	
10	T-WAY WITH RAPID JOINT	PDC9-11		
11	RAPIR JOINT	A20003	SPL-6-02	
12	RAPIR JOINT	A10003	SPL-8-02	
13	T-WAY JOINT	P02051		
14	AIR PIPE ASSY	PDC1415		
	JOINT	E60006		
	AIR PIPE	A00001		
15	JOINT ASSY	P02908	3/8"X2.5M	
16	NUT	P02043		
17	CAP	P02041		
18	JOINT	P02042		
19	NUT	P02044		
20	NUT	P02045		
21	NUT	P02046		
24	PU TUBE	P02048	φ 4X φ 2.5X φ 2.5M	
	PU TUBE	P02049	φ 5X φ 8X φ 2.5M	
	PU TUBE	P02050	φ 6X φ 8X φ 2.5M	
26	LIGHT	P02056		
27	FUSE HODER	E50901		
28	FUSE	E50051	4A	
29	POWER CORD	E23012	3CX0.75X2M	
30	WIRE	E10106	18AWG	
31	WIRE HODER	A0100-08A	UC-1	
32	WIRE CLAMP	P02057		
33	SCREW	T14006	M4X6	
34	RAPID JOINT	A10004	PF 20	

